GTR51

The GTR51 is a multisystem/multifrequency GNSS (Global Navigation Satellite System) receiver intended for time & frequency transfer. The receiver supports both code and phase measurements. Thanks to large receiver bandwidth and advanced signal processing, even the code measurements provide subnanosecond accuracy. Critical elements are placed in a thermostat box. The receiver can be directly connected to a local net/internet which allows remote control and output data download and upload.

TIME AND FREQUENCY TRANSFER GN55 RECEIVER



Operation

The operation is fully automatic. After the very first configuration, the receiver continuously collects the measurement data. Output files in several standard/proprietary formats can be generated from the collected data. The data processing can be started manually or by a scheduler which enables routine processing at given times (daily, weekly, ...). The resulting data files can be downloaded from the receiver, automatically uploaded to a server or automatically saved to an external disk. A brief message is sent to an e-mail address after the processing is finished.

The output measurement data can be referenced to the input 1PPS and/or to the output 1PPS time mark.

Remote control

The receiver can be controlled from any computer on the net. The User Interface has the form of a web page which can be accessed using a web browser. It enables control of the receiver, monitoring of the receiver operation, and download of the measurement data. Authorization is required to access the receiver.

Diagnostic system

The diagnostic system indicates several dozens of operational events and states. The diagnostic messages can be recorded in the log, displayed in the User Interface, and sent to an e-mail address.

Monitoring with graphical representation

History of operational parameters (time difference, temperature, satellite elevation/azimuth, ...) is displayed in graphs in the User Interface.

Technical parameters

Time Reference Input:

Input signal: 1PPS (leading edge)

Input impedance: 50 Ω

Trigger level: 0 - 2 V adjustable

Max level: 5.5 V / 50 Ω

Min level: -0.1 V / 50 Ω

The 1PPS mark must be coherent with the frequency reference at the 10 MHz input.

Time Reference Output:

Output signal: 1PPS (leading edge)

Low level: <0.5 V / 50 Ω High level: \rightarrow 1.8 V / 50 Ω

Frequency Reference Input:

Input signal: 10 MHz Input impedance: 50 Ω Max level: 3 Vpp / 50 Ω Min level: 0.5 Vpp / 50 Ω

Precision:

Code measurement: < 0.5 ns rms (CGGTTS data,

short-baseline common view, GPS, GALILEO, GLONASS)

Phase measurement: < 30 ps rms

(short-baseline common view)

Output Data Formats:

(all tracks / all satellites in view. · CGGTTS

MSIO iono-delay) versions 01 and 02

(observation / navigation files) RINEX

versions 2.10 (GPS only), 2.11 and 3.01 (proprietary format, all signals, both code

and carrier phase data)

EL_MASK (CNR analysis and search for obstacles)

STAT

(statistics of collected measurement data)

L3P_30s

RAW

(standard P3 data, 30 s sampling period) (P3 data, 1 s sampling period)

L3P 1s **BETA**

(proprietary format similar to planned CGGTTS V03, GPS, GALILEO, GLONASS)

(proprietary format, 1PPS_IN - 1PPS_OUT 1PPS DIF

GNSS Receiver:

Supported signals:

· GPS: L1C/A, L1P, L2C, L2P, L5

L10F, L1SF, L2OF, L2SF • GLONASS:

• GALILEO: E1. E5a · SBAS: L1, L5

Type of measurement: code / carrier phase

referenced to input / output 1PPS

Receiver bandwidth: 24 MHz

Number of satellites: all in view

Time Interval Counter:

Precision: < 15 ps rms

Thermostat: based on thermoelectric modules

Dimensions: 19"/2U standard chassis

Power Supply: 100 - 240 V AC / 50 - 60 Hz

Operating Temperature: 0 to 50°C

Antenna:

Antenna supply: 5 V / up to 90 mA

(plus on inner contact)

Recommended antenna: Novatel GPS-703-GGG

